



HOT WATER LOOP PURGING INSTRUCTIONS

1. OPEN VALVE A AND CLOSE VALVE B.
2. OPEN BOILER DRAIN A AND ALLOW SEVERAL GALLONS OF WATER TO EXIT BOILER DRAIN A.
3. CLOSE VALVE A AND OPEN VALVE B, ALLOWING SEVERAL GALLONS OF WATER TO EXIT BOILER DRAIN A.
4. OPEN BOTH VALVE A AND VALVE B, ALLOWING SEVERAL GALLONS OF WATER TO EXIT BOILER DRAIN A.
5. AFTER COMPLETING THESE STEPS CLOSE BOILER DRAIN A AND OPEN VALVES A & B.

If circulating pump is not mounted internally
It will need to be field installed.

	HYDRO-TEMP®			
	DWG NAME: Hot Water Loop			
	DATE: 3/11	SCALE:	H000026BTT	LNH