



Up to 4 zone Thermostats can be hooked to the control board. Some of the terminals will have two wires, one from each t-stat. for example 3 -4 G will have the G terminal from zone 3 and zone 4

*** TURN OFF DIPSWITCH ON CONTROL BOARD FOR EACH ZONE WITH THE PSPHA732 T-STAT**

Title					
PSPHA732 Wiring Diagram					
Project					Units
Dealer Training Manual					Inches
<small>THIS DRAWING, THE DESIGN AND DEVELOPMENTS ARE THE PROPERTY OF AND ARE NOT TO BE USED OR REPRODUCED IN ANY WAY WITHOUT WRITTEN CONSENT OF HYDRO-TEMP LTD.</small>					
DR. BY	JR	DATE	04/20/07	SCALE	DWG. NO.
REV		DATE		1:1	H004251
					1