



Up to 4 zone Thermostats can be hooked to the control board. Some of the terminals will have two wires, one from each t-stat. for example 3 -4 G will have the G terminal from zone 3 and zone 4

* TURN OFF DIPSWITCH ON CONTROL BOARD FOR EACH ZONE WITH THE PSPHA732 T-STAT

Title					
PSPHA732 Wiring Diagram					
Project					Units
Dealer Training Manual					Inches
THIS DRAWING, THE DESIGN AND DEVELOPMENTS ARE THE PROPERTY OF AND ARE NOT TO BE USED OR REPRODUCED IN ANY WAY WITHOUT WRITTEN CONSENT OF HYDRO-TEMP LTD.					
DR. BY	JR	DATE	04/20/07	SCALE	DWG. NO.
REV		DATE		1:1	H004251
					1